EV West - Hyper 9 System
ISO System - 144V - MCU, MFD

Revision 1.2 - 10/26

Note: This schematic is **only** for the **Isolated** Logic AC-X1 NetGain/SME Inverter.

Note: You must have a Pre-Charge terminal on top of your inverter to use this diagram.

Note: For correct operation you must configure the Dilithium BMS Mappable Outputs by sending the following commands through the serial interface (Putty):

SEND: `mcu> set out1 fault`
SEND: `mcu> set out2 plugin`
SEND: `mcu> set out5 power`

